

# **Application Instructions** (5/16/14)

RUST GRIP-E is a two-part epoxy coating system that has been designed with specific additives to promote adhesion when used on metal, and contains metal pigment to strengthen coating and retard chalking. RUST GRIP-E was developed to be applied to metal surfaces that cannot be dry enough to use standard RUST GRIP®. It can be used directly to wet or damp metal surfaces and maintain excellent adhesion to prevent further surface corrosion. It is a water repelling epoxy for use under water or in areas where constant splashing or condensation is a problem. It is resistant to chemicals and solvents, and is designed to can be applied directly to concrete, masonry and metal. RUST GRIP-E must be top-coated to prevent chalking.

#### **SURFACE PREPARATION**

Surface must be clean from oil, tar, rust, grease, salts, and films.

- 1) Use general degreaser if needed.
- Clean surface using TSP (tri-sodium-phosphate) or a citrus cleaner to release dirt and degreaser residue.
- 3) Pressure-wash if possible @ 3500 psi.
- 4) Salt contamination on a surface can come as a result of salt water, fertilizers, and car exhaust. Use Chlor-Rid or equivalent to decontaminate surface if salts are present. Acceptable levels: Nitrates: 5-10 mcg/cm², Sulfates: 5-10 mcg/cm², Chlorides: 3-5 mcg/cm².

## Surface should be as dry as possible before applying.

- 1) RUST GRIP-E must be applied during proper temperatures (below) and the prescribed overcoat window of the coating over which it will be applied.
- If applied over an existing coating having a glossed or shiny finish, it must be sanded and roughed to remove gloss before application, to improve the profile.
- 3) Additional coats of RUST GRIP-E can only be applied when the 1<sup>st</sup> coat becomes tacky to the touch and has little to no transfer of coating. If the first coat is allowed to cure more than 3 days to where it is not tacky, the surface must be lightly sanded to make it rough before the second coat is applied.

#### **MIXING**

- 1) Open pail, mix base with matched curing agent (4 parts base:1 part curing agent) (ratio by volume, not by weight)
- Mix by hand for two minutes, or using drill and mixing blade for a minimum of 30 seconds with NO vortex.

## **TEMPERATURE**

- 1) Apply between 40°F (4°C) and 150°F (65°C).
- Maximum temperature for continuous use when cured is 400°F (205°C).
- 3) Store unmixed product between 40°F (4°C) and 100°F (38°C) according to hazmat standards on MSDS.

#### **POT LIFE**

4-6 hours at 70°F (21°C) - 1 hour at 90°F (32°C)

## **APPLICATION**

RUST GRIP-E can be applied by brush, roller or airless sprayer; however, the preferred method is by airless sprayer.

- 1) If application is by brush, use a soft bristle brush.
- 2) If application is by roller, use a 1/2 inch nap roller.
- 3) If application is by spray, use a standard airless sprayer (1.5 gallons/minute at 3,300 psi) with a .017-.021 tip.
  - ♦ NOTE: The number of applications and the thickness of each should be in accordance with the job specifications.

## **MINIMUM SPREAD RATES (mil thickness)**

Wet Surfaces – Apply 1<sup>st</sup> application at 200 sq ft/gallon (18 sq mtr/gallon; use a roller to force coating into pores); 8 mils wet/4 mils dry ( to penetrate into pores.) Allow 4 hours to dry and ventilate well, then apply 2<sup>nd</sup> application of 100% RUST GRIP-E at 200 sq ft/gallon; 8 mils wet, 4 mils dry. Wait 24 hours and apply the last coat of RUST GRIP-E at 200 sq ft/gallon.

<u>Dry Surfaces</u> – Apply one coat (8 mils wet/4 mils dry/18 sq.mtr./gallon-200 microns wet/100 dry).

#### **CURE TIME**

**Note:** Surface and ambient temperatures will determine cure time which is normally 14 full days. Introduction of heat over surface will enhance the cure time.

Induction Period: 10 minutes at 70°F (21°C); No induction time is necessary over 90°F (32°C).

NOTE: It is critical that each coat of RUST GRIP-E be firmly adhered to the substrate before the next coat is applied. Depending on ambient and surface temperatures, it may take longer than a 24 hour recoat application window.

NOTE: May use MEK to reduce.

#### **CLEAN-UP EQUIPMENT**

- After completion, spray systems should be flushed and cleaned with MEK or other comparable solvents.
- After completion, brushes and rollers can be cleaned with MEK or comparable solvents, stored and reused.